




Lorentz Force

$$F = -e\mathbf{v} \times \mathbf{B}$$



Co-ordinate system



DETERMINATION OF HALL - COEFFICIENT OF SEMICONDUCTOR

THEORY : The Lorentz force acting on a current-carrying conductor placed in a magnetic field B applied along the z direction is Bev where, v is the drift vel of the electrons. If E_H be the Hall field developed in the y direction, then in eqⁿ.

$$e E_H = Bev \quad \text{--- (i)}$$

If n is the carrier concentration, the current density in the x direction is

$$J = nev$$

from (i) we get

$$E_H = \frac{JB}{ne} \quad \text{--- (ii)}$$

The hall coefficient is defined as the Hall field / current density per unit magnetic field.

$$R_H = \frac{E_H}{JB} = \frac{1}{ne} \quad \text{--- (iii)}$$

If a current carrying specimen of width b and thickness d is placed in a transverse magnetic field the Hall voltage (V_H) generated can be measured with the help of two probes placed at the centre of the top and bottom surfaces of the sample. Then

$$V_H = E_H d.$$

Teacher's Signature : _____

$$Q_1, V_H = R_H I B d$$

$$Q_2, V_H = R_H \frac{I}{b \cdot d} B \cdot d$$

$$Q_3, R_H = \frac{V_H b}{I \cdot B} \quad \text{--- (iv)}$$

If V_H , ~~measured~~ b , I , B are measured in SI then R_H is m^3/C .

For n-type R_H is -ve and +ve for p-type.

$$\sigma = \frac{I}{E_H} = \frac{I}{b \cdot V_H} \quad \text{--- (v)}$$

$$\text{Mobility } (\mu) = \frac{\sigma}{n e} = R_H \sigma$$

APPARATUS : n-type semiconductor Ge crystal, electromagnet, digital gauss meter, ammeter, voltmeter, power supply.

Teacher's Signature : _____

OBSERVATIONS :

$$b = 0.05 \text{ cm} =$$

$$\text{Current through sample } I = 3.05 \text{ mA}$$

$$\text{off set voltage} = -21.3 \text{ mV}$$

Sl. No.	Current through the electromagnet (A)	Magnetic field strength (H) Gauss	Hall Voltage developed V_H (mV)	Corrected Hall Voltage V_H (mV)
1.	0.99	1000	-7.8	13.5
2.	1.09	1100	-6.5	14.8
3.	1.19	1200	-5.0	16.3
4	1.29	1300	-3.7	17.6
5.	1.38	1400	-2.5	18.8
6.	1.48	1500	-1.4	20.2
7	1.57	1600	0.0	21.3
8	1.67	1700	1.2	22.5
9	1.75	1800	1.8	23.1
10	1.85	1900	3.3	24.6
11	1.95	2000	4.3	25.6
12	2.04	2100	5.7	27.0
13	2.13	2200	6.7	28.0
14	2.25	2300	8.1	29.4
15	2.35	2400	9.1	30.4
16	2.44	2500	10.2	31.5

Teacher's Signature : _____

Corrected Hall Voltage V_H (mV)
 Vs
 Magnetic field H (Gauss)

SCALE :

On X axis : 1 cm = 200 Gauss

On Y axis : 1 cm = 2 mV

Corrected Hall Voltage V_H (mV) →

34
32
30
28
26
24
22
20
18
16
14
12
10
8
6
4
2

(0,0)

1000
Magnetic Field (H)

2000

Gauss →

3000

$$\begin{aligned} \text{Slope} &= \frac{y_2 - y_1}{x_2 - x_1} \\ &= \frac{32.5 - 7.6}{2600 - 600} \\ &= \frac{24.9}{2000} \\ &= 0.01245 \end{aligned}$$

CALCULATIONS :

From the graph, slope $m = \frac{0.01295}{0.011571} \text{ mV/H}$

$$R_H = \frac{V_H \cdot b}{I \cdot B} = \frac{m \cdot b}{I \cdot B} = \frac{0.01295}{0.011571 \times 0.5 \times 10^{-4} \times 10^4} \times 3.05$$

$$= \frac{0.021229}{0.01846455}$$

$$= 0.01149 \text{ m}^3/\text{C}$$

$$= 0.021 \text{ m}^3/\text{C}$$

DISCUSSIONS :

1. Care is taken to limit the current through the probe to a value less than that mentioned by the manufacturer.
2. The probe is properly centered and oriented in the magnetic field such that max Hall voltage is generated.
3. The potential of the electromagnet power supply is kept at its min position while switching on or off the power supply.
4. In this case since R_H is +ve the majority carriers are holes.
5. Magnetic field is gradually varied in steps to avoid damage to the electromagnet.
6. The potential control of the current is brought to its min before switching on or off the current source.

Teacher's Signature : _____